

# Manual Wall paint matt

---

Wall paint matt is a premium matte wall paint that creates a smooth and even finish on walls and ceilings. Thanks to its excellent coverage and Scrub Class 2 certification, it is suitable for almost any dry interior space. The paint is made from 95% plant-based raw materials and has a low odour during application.

## Preparing a smooth surface

### Plaster

Wall paint matt is suitable for plastered surfaces and adheres excellently to substrates made of gypsum, cement and lime.

### Plasterboard

Wall paint matt is ideal for plasterboard. Finish the joints with scrim tape and a suitable jointing or finishing compound to achieve a smooth, seamless result. Once dry, lightly sand the surface and remove all dust. For the best adhesion and a perfectly even finish, we recommend applying EcoPrimer first.

### Existing wall paint

Wall paint matt can be applied over sound, well-adhered existing wall paint. Ensure the surface is clean, dry and free from dust and grease.

## Preparing with EcoPrimer

For the best adhesion and an even finish, we recommend using EcoPrimer. Apply one coat with a microfibre roller and allow it to dry completely before painting.

## Application Wall paint matt

### Step 1

You have received a tin of Wall paint matt base paint and a sachet of pigments. Always check that the label on the pigment sachet matches the colour you ordered and that it is marked 'Wall paint matt'.

Please note: the pigment formulations for Wall paint matt, Lime paint and our other paint products are different. Only use the pigments supplied specifically for Wall paint matt and add them only to the Wall paint matt base.

### Step 2

Depending on the substrate, EcoPrimer may be applied if required. EcoPrimer improves adhesion and ensures an even absorption of the surface. Apply the primer with a microfibre roller and allow it to dry completely before continuing.

### Step 3

Mix the pigments with a small amount of water in a container. To colour 1 litre of Wall paint matt, use 50–100 ml of water. Stir thoroughly using a whisk until all lumps have disappeared.

Pour the pigment mixture through a fine sieve into the paint tin. If any lumps remain, mix them again with a little water and sieve once more. Stir the Wall paint matt thoroughly until the colour is completely uniform.

### Step 4

Apply the first coat of Wall paint matt using a microfibre roller. Roll the paint on evenly without applying too much pressure. Let the roller do the work to achieve a smooth, even finish. Whenever possible, paint each wall in one go to avoid visible lap marks.

Allow the first coat to dry for at least 2 hours.

### Step 5

Apply the second coat in the same way as the first, again using a microfibre roller. Work in even strokes to achieve a smooth, uniform matte finish. Allow the second coat to dry for at least 12 hours. Once fully cured, the paint achieves its full Scrub Class 2 performance.